



Eye-Face Wash/Safety Shower Activation/Hygiene Test Log

Building _____ **Room#** _____

Date	Equipment Type <input checked="" type="checkbox"/>	Obstructed? Y/N	Flush?	Notes/Corrective Action	Initials
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				
	Eyewash Safety Shower				

Monthly Test - Eye/Face Wash

- Visual/Setup**
- Inspect For Damage/Leaks
 - Protective Caps Are In Place
 - Cleanliness/Unobstructed
 - Use Bucket To Collect Water If Not Plumbed-EHS To Provide

- Physical**
- Activate Valve-Should Stay Open-Manual Shut Off Only
 - Verify Adequate Flow-Streams Should Cross So Both Eyes Can Be Rinsed- Without Injuring User With Overpressure
 - Caps Should Pop Off Automatically When Valve Is Opened
 - Run Water For 60 Seconds To Flush-Document

Quarterly Test - Safety Shower

- Visual/Setup**
- Inspect For Damage/Leaks
 - Pull/Push Rod Is In Place
 - Cleanliness/Unobstructed
 - Use Shower Test Equipment-Collection Barrel & Shower Curtain-EHS To Provide

- Physical**
- Turn On Water-Pull/Push-Rod Should Be Easily Activated
 - Verify Adequate Flow-Should Be Able To Provide 20 Gallons Per Minute-Collection Barrel Is Marked To Estimate Flow
 - Run Water For 15 Seconds To Flush